

SPEC-D *Tuning*

2000-2005 MITSUBISHI ECLIPSE PROJECTOR HEADLIGHTS INSTALLATION INSTRUCTIONS

If you experience any difficulties that the instruction did not cover, Please seek assistance at a local automotive shop

Please wear protection before you work on any vehicle.



An assistant is useful when removing the front bumper from your vehicle.

Please be cautious when working with the bumper or any parts belonging to the vehicle's body to prevent scratching.

Do not make direct contact with the halogen bulbs or the wire assembly until the unit has cooled down after use.

TOOLS AND SUPPLIES REQUIRED

1/4" Drive Ratchet

6" Extension

10mm Socket

Handy Remover

If your Headlight is Halo type, you also need:

Wire Stripper

Wire Crimper

4 Blue Quick Splice Wire Connectors

4 Blue Male Quick Wire Connectors

4 Blue Female Quick Wire Connectors

2 Red Wires (8 inch)

2 Black Wires (8 inch)

Product Part Numbers:

LHP-ELP00JM-RS

LHP-ELP00-RS



2000-2005 MITSUBISHI ECLIPSE PROJECTOR HEADLIGHTS INSTALLATION INSTRUCTIONS

If you experience any difficulties that the instruction did not cover, Please seek assistance at a local automotive shop

Please wear protection before you work on any vehicle.



An assistant is useful when removing the front bumper from your vehicle.

Please be cautious when working with the bumper or any parts belonging to the vehicle's body to prevent scratching.

Do not make direct contact with the halogen bulbs or the wire assembly until the unit has cooled down after use.



1. Open the hood



2. (3) 10mm bolt locations



3. Remove the (3) 10mm bolts



4. Remove the headlight



5. Disconnect the headlight harness



6. Connect the headlight harness to the projector headlight

Please see the "L. E. D. tail lights installation instructions"
If your tail lights don't have L. E. D. You can skip the installation instructions.



7. Place the projector headlight in the stock location



8. Tighten the (3) 10mm bolts



9. Tighten the (3) 10mm bolts



10. Please repeat the steps in order from 1 to 9 for the opposite side. The installation now is complete.