

SPEC-D *Turning*

2003-2006 CHEVY SILVERADO TOWING MIRRORS INSTALLATION INSTRUCTIONS

*If you experience any difficulties that the instructions did not cover, Please seek assistance at local automotive shop.

*Please wear protection before you work on your vehicle.

*An assistant is useful when removing the front bumper from your vehicle.

*Please be cautious when working with the bumper or any parts belonging to the vehicles' body prevent scratching.

*Do not make direct contact with the halogen bulb or the wire assembly until the unit has cooled down after use.



TOOLS AND SUPPLIES REQUIRED

1/2" Drive Ratchet

T20 Socket

6" Extension

Trim Pad Remover

10mm Socket

7mm Socket

Product Part Numbers:

RMX-SIV03H-P-FS



*If you experience any difficulties that the instructions did not cover, Please seek assistance at local automotive shop.
*Please wear protection before you work on your vehicle.
*An assistant is useful when removing the front bumper from your vehicle.
*Please be cautious when working with the bumper or any parts belonging to the vehicles' body prevent scratching.
*Do not make direct contact with the halogen bulb or the wire assembly until the unit has cooled down after use.



1. Remove the door trim



2. Remove the foam insulation



3. Remove the door lock switch



4. Remove the 7mm screw



5. Remove the plastic clip



6. Remove the plastic cover



7. Remove the T20 bolt



8. Remove the inside handle bezel



9. 7mm screw location



10. Remove the 7mm screw



11. Lift the door panel up and away from the door



12. Peel away the plastic sheet



13. Unclip the mirror harness



14. Disconnect the mirror harness



15. Remove the mirror harness from under the plastic sheet



16. (3) 10mm nuts location



17. Remove the (3) 10mm nuts



18. Unclip the mirror



19. Remove the stock mirror



20. Place the new mirror in the stock location



21. Tighten the (3) 10mm nuts



22. Run the mirror harness under the plastic sheet



23. Attach the harness clips to the door



24. Replace the plastic sheet



25. Connect the mirror harness to the switch panel



26. Replace the door panel



27. Tighten the 7mm screw



28. Replace the door lock switch



29. Replace the plastic clip



30. Replace the plastic bolt cover and tighten the T20 bolt



32. Replace the inside handle bezel



33. Replace the foam insulation



34. Replace the door trim
Please repeat the steps in order from 1 to 34 for the opposite side



35. The installation is now complete