

PART NO. 82105

Instruction Sheet

GM REAR CAM BOLTS

This part should only be installed by personnel who have the necessary skill, training and tools to do the job correctly and safely. Incorrect installation can result in personal injury, vehicle damage and / or loss of vehicle control.

Plan Ahead - Read All Instructions BEFORE installing part

Always check for loose or worn parts, tire pressure and odd tire wear patterns.

1. Raise rear of vehicle and support by frame.
2. Pre-assemble SPC cams by placing one cam onto each bolt.
3. One at a time, remove factory cam bolt assemblies and install SPC bolt/cam.
4. Place second cam over protruding end of each bolt and install nut, loosely tighten.
5. Lower vehicle.
6. Adjust alignment by turning bolts to achieve desired settings. Once desired setting is achieved, hold bolts from rotating and tighten nuts to 105 lb-ft.
7. Adjust toe, recheck alignment and road test vehicle.

Always check for proper clearance between suspension components and other components of the vehicle.



**Specialty
Products
Company**