

PART NO. 82070

Instruction Sheet

SOLSTICE/SKY CAM BOLTS

This part should only be installed by personnel who have the necessary skill, training and tools to do the job correctly and safely. Incorrect installation can result in personal injury, vehicle damage and / or loss of vehicle control.

Plan Ahead - Read All Instructions BEFORE installing part.

1. Raise vehicle and support by frame.
2. Remove OE cam and bolt assembly.
3. Install SPC bolt with a cam on each side.
Loosely install nut.

NOTE: Tightening fasteners with vehicle in raised position will cause premature bushing failure.

4. Lower vehicle.
5. Compensate alignment equipment and adjust alignment using cams.
6. When finished adjusting, hold head of bolt and torque nut to manufacturer's specification.
7. Complete alignment and road test vehicle.

Always check for proper clearance between suspension components and other components of vehicle.



***Specialty
Products
Company***®