

PART NO. 87385

Instruction Sheet

F150/250 (L/D) RWD AND 4WD CAMBER /CASTER KIT

This part should only be installed by personnel who have the necessary skill, training and tools to do the job correctly and safely. Incorrect installation can result in personal injury, vehicle damage and / or loss of vehicle control.

1. Remove the tire and wheel assembly.
 2. Remove the OE upper control arm bolts and replace with #87385 cam bolts.
 3. Install other cam and nut on each cam bolt and tighten lightly.
 4. Adjust the cam bolts from the bolt head side of the bolt to the desired caster/camber settings.
 5. While holding the cam bolts from rotating, torque all nuts to manufacturers' specifications.
-



**Specialty
Products
Company®**