



## Installation Instructions

P/N 42724 (chrome) - P/N 42724G (bronze)

P/N 42724K (black) - P/N 42724S (silver)

### Step 1

Clean the top of the factory radiator cap with alcohol to remove any dirt, oil or contaminants.

### Step 2

Peel the backing film off the double sided tape. Place the cover onto the stock radiator cap and press firmly to set.

**ATTENTION:** Do not use harsh chemicals to clean covers.

[Performance Air Filters](#)