

Installation Instructions

P/N 42823 ([chrome](#)) - P/N 42823G (bronze)

P/N 42823K (black) - P/N 42823S (silver)


Step 1

Clean the top of the factory coolant reservoir cap with rubbing alcohol to remove any dirt, oil or contaminants.

Step 2

Peel the backing film off the double sided tape, then place the cap cover onto the factory cap and press firmly to set.

ATTENTION: Do not use harsh chemicals to clean covers.

 **WARNING** This product can expose you to a chemical or chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.