



Installation Instructions


P/N 42922 ([chrome](#)) - P/N 42922G (bronze)

P/N 42922K (black) - P/N 42922S (silver)

Step 1

Place the cap cover onto the factory brake fluid reservoir cap and press firmly to install until the tabs engage fully around the stock cap.

ATTENTION: Do not use harsh chemicals to clean covers.

 **WARNING** This product can expose you to a chemical or chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.