



Installation Instructions

P/N 42762 (chrome) - P/N 42762K (black)

Step 1

Before you permanently install the lid, place it onto the factory air box to ensure proper fit and alignment.

Step 2

Then clean the top of the factory air box with alcohol to remove any dirt, oil or contaminants.

Step 3

Peel the backing film off the double sided tape. Place the lid onto the air box making sure it aligns properly and press firmly to set.

ATTENTION: Do not use harsh chemicals to clean covers.

Learn more about chrome trim and accessories we have.