

SPECTRE™

Installation instructions

1. Remove all original bolts on your factory air box/air sensor tube.
2. Compare the mounting holes on your existing mass airflow sensor to the adapter plate (PN81413).
Note: If the pre-drilled holes do not line up with your vehicle's sensor, you can mark the plate with a permanent marker (make sure to line up tube to adapter carefully), center punch the marks, and then carefully drill the holes to match.
3. If possible, re-use the factory bolts to attach the adapter plate to the factory airflow/temperature sensor unit. It may be necessary to replace the factory bolts with a different nut/bolt combination (not supplied).
4. If your vehicles airflow/temperature sensor is equipped with a square hole you must use the included black plate.
5. Make sure all bolts and clamps are tightened to avoid air leaks.