



# SPYDER

## INSTALLATION GUIDE: ALT-YD-CHR305-(ALL COLORS)

### Tools Required No Tools Required

**\*Please Note\***

If you are unfamiliar with the installation processes, professional installation is highly recommended.



1) Open the trunk.



2) Remove [1x] Thumbscrew that secures the trunk liner, then peel back the liner for access.



3) Remove [2x] Thumbscrews securing the tail light.



4) Unlock the red tab, then disconnect the tail light harness.



5) Unseat the tail light.



6) Remove the reverse lamp socket, then remove the bulb from the socket. Never touch exposed bulbs with bare hands.



7) Transfer the reverse bulb to the black and white wire reverse socket of the Spyder tail light. Then reinstall the socket.



8) Feed the harness through the opening, being sure to seat the wiring harness grommet.



9) Seat the Spyder tail light.



10) Reinstall [2x] thumbscrews to secure the tail light.



11) Reconnect the tail light wiring harness, then lock the red tab.



12) Replace the trunk liner and install [1x] thumb-screw.



13) Close the trunk and enjoy your Spyder LED tail lights.