



SPYDER

INSTALLATION GUIDE: ALT-YD-CSUB07-LED-(ALL COLORS)

Tools Required Phillips Screwdriver



Please Note

If you are unfamiliar with the installation processes,
professional installation is highly recommended.



1) Open the tailgate. Remove [2x] phillips screws
securing the tail light.



2) Unseat the tail light.



3) Remove the bulb sockets from the OEM tail
light.



4) Disconnect the tail light harness.



5) Remove the bulb socket harness and set it aside.



6) Connect the Spyder harness to the tail light harness in place of the bulb socket harness.



7) Seat the Spyder tail light.



8) Reinstall [2x] phillips screws to secure the tail light.



9) Close the tailgate and enjoy your new LED tail lights from Spyder Auto.