



SPYDER

INSTALLATION GUIDE:

ALT-YD-FF15009-LED-(ALL COLORS)

Tools Required

8mm Socket + Ratchet



Please Note

If you are unfamiliar with the installation processes, professional installation is highly recommended.



1) Open the tailgate. Remove the two 8mm bolts securing the tail light.



2) Unseat the tail light.



3) Disconnect the brake light and turn signal wiring harnesses, then remove the reverse lamp bulb socket.



4) Locate your SPYDER tail light. Connect the OEM wiring harness to your SPYDER tail light. Be sure to install the reverse lamp bulb socket.



5) Seat the SPYDER tail light.



6) Reinstall the two 8mm bolts to secure the tail light.



7) Enjoy your new SPYDER LED Tail lights.