



# SPYDER

WWW.SPYDERAUTO.COM

## INSTALLATION GUIDE: ALT-YD-FF15015-LBLED-(All)

### Tools Needed:

- ¼" ratchet
- 8mm socket



1. Remove (2x) 8mm bolts.



2. Unseat tail light.



3. Remove reverse light socket. (Never touch bulb with bare hands)



4. Unclip brake light harness.



5. Connect brake light harness to Spyder tail light.



6. Plug reverse light socket into Spyder tail light.



7. Seat Spyder tail light.



8. Reinstall (2x) 8mm bolts.



9. Turn on lights and confirm all functions are working properly. You have successfully completed the install of your new Spyder LED tail lights.



# SPYDER

WWW.SPYDERAUTO.COM

For further help with installation, please watch our installation video.

Follow the direct link below to our YouTube channel for more  
information:

<http://www.youtube.com/watch>

## **DISCLAIMER**

Spyder Auto Installation Guide is not liable for damages, injuries, and death while installing the product. This is intended to be an installation guide, to reduce installation time. We have no responsibility for improper installation. If you do not know how to install, please have a professional install it.