



SPYDER

INSTALLATION GUIDE: ALT-YD-FR98-LED-(ALL COLORS)

Tools Required Phillips Screwdriver



Please Note

If you are unfamiliar with the installation processes,
professional installation is highly recommended.



1) Open the tailgate.



2) Remove [2x] inner phillips screws along the
tailgate sill securing the tail light.



3) Remove the [2x] outer phillips screws
securing the tail light.



4) Unseat the tail light, then disconnect the reverse
harness and the park/brake/turn harness.



5) Remove the brake/park/turn signal and reverse lamp sockets from the OEM tail light. Never touch exposed bulbs with bare hands.



6) Remove the brake/park/turn signal bulb from the socket.



7) Line up the black wire side of the Spyder socket insert with the ground wire side of the brake/park/turn signal socket to ensure correct polarity, then install the socket.



8) Install the reverse socket into the Spyder tail light.



9) Reconnect the reverse lamp and brake/park/turn signal harnesses.



10) Seat Spyder tail light.



11) Reinstall [2x] outer phillips screws to secure the tail light.



12) Reinstall [2x] phillips screws securing the tail light along the tailgate sill.



13) Close the tailgate and enjoy your new Spyder LED Tail lights.