



# SPYDER

WWW.SPYDERAUTO.COM

## INSTALLATION GUIDE: ALT-YD-FR98-LED-(All)

### Tools Needed:

- Phillips screwdriver



1. Remove (2x) phillips screws.



2. Remove (2x) outer phillips screws.



3. Unseat tail light.



4. Disconnect Brake and reverse light harness.



5. Remove brake and reverse light sockets.



6. Remove brake bulb from socket and insert Spyder socket insert into brake socket. (Make sure to align black wire of socket to black wire of socket insert)



7. Install reverse socket onto Spyder tail light.



8. Connect brake and reverse harness to Spyder tail light.



9. Seat Spyder tail light.



10. Reinstall (2x) outer screws and (2x) inner screws.



11. Turn on lights and confirm all functions are working properly. You have successfully completed the install of your new Spyder LED tail lights.



# SPYDER

WWW.SPYDERAUTO.COM

For further help with installation, please watch our installation video.

Follow the direct link below to our YouTube channel for more information:

<http://www.youtube.com/watch>

## **DISCLAIMER**

Spyder Auto Installation Guide is not liable for damages, injuries, and death while installing the product. This is intended to be an installation guide, to reduce installation time. We have no responsibility for improper installation. If you do not know how to install, please have a professional install it.