



SPYDER

WWW.SPYDERAUTO.COM

INSTALLATION GUIDE: ALT-YD-FS07V3-LBLED-(All)

Tools Needed:

- ¼" ratchet
- 8mm socket
- Panel popper



1. Remove (2x) 8mm bolts.



2. Unseat tail light using panel popper.



3. Remove brake and reverse light sockets.
(Make sure to not touch bulb with bare hands)



4. Remove brake light bulb from sock and install brake socket insert into brake socket. (Make sure to align black wire of socket to black wire of socket insert)



5. Install brake and reverse sockets onto Spyder tail light



6. Seat Spyder tail light.



7. Install (2x) 8mm bolts.



8. Turn on lights and confirm all functions are working properly. You have successfully completed the install of your new Spyder LED tail lights.



SPYDER

WWW.SPYDERAUTO.COM

For further help with installation, please watch our installation video.

Follow the direct link below to our YouTube channel for more information:

<http://www.youtube.com/watch>

DISCLAIMER

Spyder Auto Installation Guide is not liable for damages, injuries, and death while installing the product. This is intended to be an installation guide, to reduce installation time. We have no responsibility for improper installation. If you do not know how to install, please have a professional install it.