



SPYDER

INSTALLATION GUIDE:

ALT-YD-JWA07-LED-(ALL COLORS)

Tools Required

Phillips Screwdriver



Please Note

If you are unfamiliar with the installation processes, professional installation is highly recommended.



1) Remove [2x] phillips screws securing the tail light.



2) Unseat the tail light.



3) Disconnect the wiring harness.



4) Connect the Spyder LED tail light to the wiring harness.



5) Seat the Spyder tail light.



6) Reinstall [2x] Phillips Screws to mount the tail light.



7) Enjoy your new Spyder LED tail lights.