



# SPYDER

## INSTALLATION GUIDE:

ALT-YD-LRRRS06-LED(ALL COLORS)

### Tools Required

Flat Head Screwdriver

**\*Please Note\***

If you are unfamiliar with the installation processes, professional installation is highly recommended.



1) Open your trunk to reveal the tail light assembly. Using a flat head screwdriver, remove the two screws holding the light in place (arrow 1). Once removed, you will need to pry the assembly free. If removal by hand proves difficult, you may also use the flat driver with a towel or cloth around it to gently and carefully pry the assembly free (arrow 2).



2) Once you have unseated the tail light, flip the light over. Attached will be the OEM harness. There is usually a small pressure clip/latch attached to the harness that needs to be squeezed together in order to release the harness. Squeeze, then pull apart. Once this is done, set OEM assembly aside.



3) With the new light in hand, attach the Spyder harness to the OEM harness, The connector should \*click\* in place.



4) Reseat the tail light assembly by pressing it into place and being sure to line it up flush with the body. Reinstall the two screws and you're done!