



SPYDER

INSTALLATION GUIDE: ALT-YD-TT95-LED-(ALL COLORS)

Tools Required Phillips Screwdriver



Please Note

If you are unfamiliar with the installation processes, professional installation is highly recommended.



1) Remove the four phillips head screws which secure the tail light to the body.



2) Unseat the tail light.



3) Disconnect the tail light wiring harness from the OEM tail light.



4) Remove the lens from the OEM tail light, remove the reverse lamp bulb and transfer it to your new SPYDER tail light before installing it.



5) Connect the SPYDER tail light's wiring harness to the OEM tail light wiring harness.



6) Seat the SPYDER headlight and reinstall the four phillips screws that secure it to the body.



7) Enjoy your new SPYDER LED tail lights.