



SPYDER

INSTALLATION GUIDE: ALT-YD-TTU07-LED-(ALL COLORS)

Tools Required T30 Torx Screwdriver



Please Note

If you are unfamiliar with the installation processes, professional installation is highly recommended.



1) Open the tailgate and remove the two T30 torx screws securing each tail light.



2) Gently pull outwards to unseat the taillight.



3) Remove the bulb sockets from the OEM tail light housing. Retain the reverse and turn signal bulbs, but remove the brake lamp bulb from its socket.



4) Connect the SPYDER tail light's wedge socket insert harness to the brake lamp bulb socket. Be sure to line up the black wires on both sides of the harness. Failure to do so can cause electrical problems and will void your warranty.



5) Install the turn signal, reverse and brake lamp sockets into the SPYDER tail light housing. Be sure to retain all bulb socket gaskets and to twist each socket securely into place, then seat the SPYDER tail light.



6) Unseat the rear bumper fascia by pulling the edges of the fascia outwards.



7) Enjoy your new SPYDER LED tail lamps.