



SPYDER

WWW.SPYDERAUTO.COM

INSTALLATION GUIDE: PRO-YD-BMW E9005V2-AM-BK

Tools Needed:

- ¼" ratchet
- 8mm and 10mm socket
- Phillips screwdriver
- T30 Torx



1. Remove (4x) T30 torx.



2. Remove (7x) phillips screws from below the front bumper fascia.



3. Remove (2x) 8mm screws on each side of the fascia.



4. Remove (2x) phillips screws behind fender liner on each side.



5. Unseat front bumper fascia.



6. Disconnect both fog lamps.



7. Remove (2x) 10mm headlight bolts.



8. Remove (2x) T30 torx screw.



9. Remove (1x) T30 torx screw from behind the headlight corner.



10. Unseat headlight.



11. Disconnect headlight harness.



12. Remove (2x) 10mm bolts securing headlight bracket to headlight.



13. Install bracket onto Spyder headlight using (2x) 10mm bolts.



14. Connect Spyder headlight harness.



15. Seat Spyder headlight.



16. Install (2x) 10mm bolt on top of headlight.



17. Reinstall (2x) T30 torx screws.



18. Reinstall (1x) T30 torx screw from behind the corner of headlight.



19. Reinstall both fog lamp bulbs.



20. Seat bumper fascia.



21. Reinstall (4x) T30 torx.



22. Reinstall (2x) screws on each side securing bumper.



23. Reinstall (2x) 8mm screws securing fender liner on each side.



24. Reinstall (7x) screw on the bottom of the bumper fascia.



25. Turn on lights and confirm all functions are working properly. You have successfully completed the install of your new Spyder Headlights.



SPYDER

WWW.SPYDERAUTO.COM

For further help with installation, please watch our installation video.

Follow the direct link below to our YouTube channel for more information:

<http://www.youtube.com/watch>

DISCLAIMER

Spyder Auto Installation Guide is not liable for damages, injuries, and death while installing the product. This is intended to be an installation guide, to reduce installation time. We have no responsibility for improper installation. If you do not know how to install, please have a professional install it.