



# SPYDER

WWW.SPYDERAUTO.COM

## INSTALLATION GUIDE: PRO-YD-BMWZ403-HL-(All)

### Tools Needed:

- ¼" ratchet
- 8mm socket
- Panel popper
- T25 and T30 Torx



1. Remove (7x) T30 torx bolts along top of bumper fascia.



2. Remove hood weather strip.



3. Remove (4x) plastic retainer clips in fender well.



4. Remove (7x) 8mm bolts securing fascia to the under tray.



5. Unseat bumper and disconnect fog lights/corner lights.



6. Remove front bumper fascia.



7. Remove (4x) T25 torx bolts securing the headlight.



8. Unseat headlight.



9. Disconnect HID harness (Note this connector will no longer be used).



10. Disconnect headlight harness.



11. Connect Spyder headlight harness (Be sure to lock harness securely).



12. For info on how to wire halos please refer to the Spyder FAQ playlist on the Spyder Auto YouTube channel.



13. Seat Spyder headlight.



14. Reinstall (4x) T25 torx bolts.



15. Seat bumper and reconnect fog lights/corner lights.



16. Seat bumper fascia.



17. Reinstall hood weather strip and (7x) T30 torx bolts securing the bumper fascia.



18. Reinstall (4x) retaining clips.



19. Reinstall (7x) 8mm bolts.



20. Turn on lights and confirm all functions are working properly. You have successfully completed the install of your new Spyder Headlights.



# SPYDER

WWW.SPYDERAUTO.COM

For further help with installation, please watch our installation video.

Follow the direct link below to our YouTube channel for more  
information:

<http://www.youtube.com/watch>

## **DISCLAIMER**

Spyder Auto Installation Guide is not liable for damages, injuries, and death while installing the product. This is intended to be an installation guide, to reduce installation time. We have no responsibility for improper installation. If you do not know how to install, please have a professional install it.