



SPYDER

WWW.SPYDERAUTO.COM

INSTALLATION GUIDE: PRO-YD-CCO04-HL-(All)

Tools Needed:

- ¼" ratchet
- 10mm socket



1. Push down on (4x) plastic clips securing the grill.



2. Push down to release.



3. Disconnect turn signal harnesses.



4. Remove grill assembly.



5. Remove (2x) 10mm bolts securing headlight.



6. Unseat headlight.



7. Disconnect high and low beam harnesses.



8. Connect Spyder high and low beam harnesses.



9. For info on how to wire halos please refer to the Spyder FAQ playlist on the Spyder Auto YouTube channel.



10. Seat Spyder headlight.



11. Reinstall (2x) 10mm bolts securing headlight.



12. Seat grill assembly making sure to lock in clips.



13. Reconnect turn signal harnesses.



14. Turn on lights and confirm all functions are working properly. You have successfully completed the install of your new Spyder Headlights.



For further help with installation, please watch our installation video.
Follow the direct link below to our YouTube channel for more
information:

<http://www.youtube.com/watch>

DISCLAIMER

Spyder Auto Installation Guide is not liable for damages, injuries, and death while installing the product. This is intended to be an installation guide, to reduce installation time. We have no responsibility for improper installation. If you do not know how to install, please have a professional install it.