



SPYDER

WWW.SPYDERAUTO.COM

INSTALLATION GUIDE:

PRO-YD-FF15004-CCFL-G2-(All)

Tools Needed:

- ¼" ratchet
- 10mm socket
- Phillips screw driver



1. Remove (1x) phillips crew retainer.



2. Pull back weather strip.



3. Remove (3x) 10mm bolts.



4. Unseat the headlight.



5. Remove turn signal and side marker socket. Disconnect headlight harness.



6. For info on how to wire halos please refer to the Spyder FAQ playlist on the Spyder Auto YouTube channel.



7. Install turn signal and side marker socket onto Spyder headlight (Make sure to never touch bulbs with bare hands).



8. Connect Spyder headlight harness.



9. Seat Spyder headlight.



10. Reinstall (3x) 10mm bolts.



11. Reseat weather strip and install retainer.



12. Turn on lights and confirm all functions are working properly. You have successfully completed the install of your new Spyder Headlights.



SPYDER

WWW.SPYDERAUTO.COM

For further help with installation, please watch our installation video.

Follow the direct link below to our YouTube channel for more
information:

<http://www.youtube.com/watch>

DISCLAIMER

Spyder Auto Installation Guide is not liable for damages, injuries, and death while installing the product. This is intended to be an installation guide, to reduce installation time. We have no responsibility for improper installation. If you do not know how to install, please have a professional install it.