



SPYDER

WWW.SPYDERAUTO.COM

INSTALLATION GUIDE: PRO-YD-TCAM02-DRL-(All)

Tools Needed:

- ¼" ratchet
- 10mm socket
- Panel Popper



1. Remove (2x) 10mm bolts securing the bumper fascia.



2. Using panel popper remove (1x) plastic retainer.



3. Below the bumper remove (7x) 10mm bolts securing the bumper.



4. Pull back fender liner and remove (1x) 10mm bolt securing the corner of the bumper.



5. Carefully unseat the bumper fascia.
(Disconnect fog light harnesses if equipped)



6. Remove (2x) 10mm bolts securing the headlight.



7. Pull up and unseat the headlight.



8. Disconnect high beam, low beam and turn signal harnesses.



9. Connect high beam, low beam and turn signal harnesses onto Spyder headlight.



10. Seat Spyder headlight.



11. Reinstall (2x) 10mm bolts to secure Spyder headlight.



12. Seat front bumper fascia. (Reconnect fog light harnesses if equipped)



13. Reinstall (1x) 10mm bolt securing the corner of the bumper fascia.



14. Reinstall (7x) 10mm bolts securing the bottom of the bumper fascia.



15. Reinstall (2x) 10mm bolts and (1x) plastic retainer securing the top of the bumper fascia.



16. Turn on lights and confirm all functions are working properly. You have successfully completed the install of your new Spyder Headlights.



SPYDER

WWW.SPYDERAUTO.COM

For further help with installation, please watch our installation video.

Follow the direct link below to our YouTube channel for more
information:

<http://www.youtube.com/watch>

DISCLAIMER

Spyder Auto Installation Guide is not liable for damages, injuries, and death while installing the product. This is intended to be an installation guide, to reduce installation time. We have no responsibility for improper installation. If you do not know how to install, please have a professional install it.