



SPYDER

WWW.SPYDERAUTO.COM

INSTALLATION GUIDE: PRO-YD-TCEL00-LED-(All)

Tools Needed:

- ¼" ratchet
- 10mm socket



1. Remove (1x) 10mm bolt securing the corner of the bumper fascia.



2. Remove (5x) 10mm bolts securing the top of the bumper fascia.



3. Remove (1x) plastic clip.



4. Remove the bumper fascia.



5. Remove (1x) 10mm bolt and (2x) 10mm nuts securing the headlight bracket.



6. Remove (3x) 10mm bolts securing the headlight.



7. Unseat the headlight.



8. Remove all sockets and disconnect headlight harnesses.



9. For info on how to wire halos please refer to the Spyder FAQ playlist on the Spyder Auto YouTube channel.



10. Reconnect all harnesses and install all sockets. Seat Spyder headlight.



11. Reinstall headlight bracket and all 10mm nuts and bolts.



12. Seat the bumper fascia and install 10mm bolts securing the corners.



13. Reinstall (5x) 10mm bolts and (1x) plastic clip.



14. Turn on lights and confirm all functions are working properly. You have successfully completed the install of your new Spyder Headlights.



SPYDER

W W W . S P Y D E R A U T O . C O M

For further help with installation, please watch our installation video.

Follow the direct link below to our YouTube channel for more
information:

<http://www.youtube.com/watch>

DISCLAIMER

Spyder Auto Installation Guide is not liable for damages, injuries, and death while installing the product. This is intended to be an installation guide, to reduce installation time. We have no responsibility for improper installation. If you do not know how to install, please have a professional install it.