



SPYDER

WWW.SPYDERAUTO.COM

INSTALLATION GUIDE: PRO-YD-TTU07-CCFL-(All)

Tools Needed:

- ¼" ratchet
- 10mm socket
- Panel popper



1. Remove (2x) plastic retainers using the panel popper.



2. Unseat and remove headlight garnish.



3. Remove (3x) 10mm bolts securing the headlight.



4. Unseat the headlight.



5. Disconnect low beam and high beam harness. Remove turn signal socket and side marker socket.



6. For info on how to wire halos please refer to the Spyder FAQ playlist on the Spyder Auto YouTube channel.



7. Connect low beam and high beam harnesses onto Spyder headlight.



8. Install side marker and turn signal socket.



9. Seat Spyder headlight.



10. Install (3x) 10mm bolts securing the Spyder headlight.



11. Seat headlight garnish.



12. Install (2x) plastic retainers.



13. Turn on lights and confirm all functions are working properly. You have successfully completed the install of your new Spyder Headlights.



SPYDER

WWW.SPYDERAUTO.COM

For further help with installation, please watch our installation video.

Follow the direct link below to our YouTube channel for more information:

<http://www.youtube.com/watch>

DISCLAIMER

Spyder Auto Installation Guide is not liable for damages, injuries, and death while installing the product. This is intended to be an installation guide, to reduce installation time. We have no responsibility for improper installation. If you do not know how to install, please have a professional install it.