



SPYDER

INSTALLATION GUIDE: PRO-YD-CM04-(ALL COLORS)

Tools Required
10mm Socket + Ratchet



Please Note

If you are unfamiliar with the installation processes,
professional installation is highly recommended.



1) Open the hood. Remove [2x] 10mm bolts securing the headlight.



2) Unseat the headlight.



3) Disconnect the wiring harness and set the OEM headlight aside.



4) Connect the wiring harness to your Spyder headlight.

Spyder Auto's custom lights can make your vehicle look better and increase your safety.



5) Seat the Spyder headlight.



6) Reinstall [2x] 10mm bolts to mount the headlight.



7) Close the hood and enjoy your new Spyder headlights.

We offer direct replacement factory headlights, as well as a huge selection of custom headlights in your choice of styles and lighting options.