



SPYDER

INSTALLATION GUIDE: PRO-YD-DR06-(ALL COLORS)

Tools Required

10mm Socket wrench/ratchet
T25 Torx



Please Note

If you are unfamiliar with the installation processes, professional installation is highly recommended.



1) Open the hood. Remove the two T25 Torx screws securing the headlight.



2) Move to the wheel well and remove the rubber access plug indicated.



3) Using the access hole in the fender well, use a 10mm socket to remove the 10mm nut securing the headlight from behind, indicated here.



4) Unseat the headlight by gently pulling it forward.



5) Disconnect the headlight bulb wiring harness and turn signal bulb.



6) Locate your SPYDER headlight. Reinstall the turn signal bulb/socket into the SPYDER headlight housing by twisting it into place. Take care to ensure all bulb socket gaskets are in place and all vent hoses face down to prevent condensation.



7) Remove the OEM headlight bulb from the socket.



8) Connect the wiring harness from the SPYDER headlight to the OEM headlight harness.



9) Seat the SPYDER headlight.



10) Reinstall the two T-25 Torx Screws securing the headlight.



11) Reinstall the 10mm nut that secures the headlight from behind through the fenderwell access hole.



12) Reinstall the fenderwell access plug.



13) Close the hood & enjoy your new SPYDER headlights.