

SIT[®]

SUSPENSIONS



made by 

Installation Instructions		<i>KW automotive</i>	
Instruction No.	688 10 00K	Date	11.08.2021

KW automotive

INSTALLATION INSTRUCTIONS

**Before you start installation work,
please read the following carefully:**

- **Ensure that the certificate matches the vehicle specifications (front vehicle identification number (VIN)) etc...**
- **The suspension components must match the suspensions application specifications (springs and shock/struts identification numbers).**
- **The instructions have to be strictly observed.**

KW Coilovers for automobile suspensions are designed for easy installation. If not otherwise stipulated in these instructions, all suspension components are installed and removed in accordance with the manufacturer's specifications for installing and removing standard springs and damper components. At the time of printing all instructions and specifications are correct.


Installation Instructions			KW automotive	
Instruction No.	688 10 00K		Date	11.08.2021

Technical data		Part number 253 10 00K / 273 10 00K			
Vehicle model		Audi Quattro RS6 station wagon type 4G		max. permissible front axle load: 1310 kg	
		front axle		rear axle	
Spring signature		10-70-70 / 1042		1043	
Coilover strut / Shock absorber signature		-		-	
Approximate distance measurement A		min: max:		min: max:	
Front axle: Fastening screw - spring contact area					
Rear axle: Seating height adjustment - spring contact area or fastening screw - spring contact area		220 mm / 8,7 inch 235 mm / 9,3 inch		40 mm / 1,6 inch 55 mm / 2,2 inch	
Approximate measurement* B in mm / inch: wheel hub center to fender edge		min:		min:	
		350 mm / 13,8 inch		345 mm / 13,6 inch	

Vehicle model		Audi Quattro RS7 Sportback type 4G		max. permissible front axle load: 1310 kg	
		front axle		rear axle	
Spring signature		10-70-70 / 1042		1043	
Coilover strut / Shock absorber signature		-		-	
Approximate distance measurement A		min: max:		min: max:	
Front axle: Fastening screw - spring contact area					
Rear axle: Seating height adjustment - spring contact area or fastening screw - spring contact area		220 mm / 8,7 inch 235 mm / 9,3 inch		40 mm / 1,6 inch 55 mm / 2,2 inch	
Approximate measurement* B in mm / inch: wheel hub center to fender edge		min:		min:	
		360 mm / 14,2 inch		360 mm / 14,2 inch	

Installation Instructions			KW automotive	
Instruction No.	688 10 00K		Date	11.08.2021

Calculating the adjustment range (distance measurement A) : (Photos are examples only)



Measurement B
Wheel hub center - fender edge

Please enter the adjusted height of the modified car into the list:

Coilover part no	Vehicle type	Measurement A		Wheel hub center - fender edge Measurement B	
		Front	Rear	Front	Rear

* **IMPORTANT:** The allowable measurement between wheel hub center and fender edge as indicated above, may not exceed these measurements when using standard fenders.

Installation Instructions		<i>KW automotive</i>	
Instruction No.	688 10 00K	Date	11.08.2021



Danger:

1. Always follow the latest accident prevention regulations (not applicable for North America) for each step to prevent any serious bodily harm or injury.
2. We recommend the use of a vehicle hoist or lift when installing the suspension. If a lift is not available and jacking equipment is used, make sure that the vehicle is secured with commercial wheel blocks and jack stand to ensure safety.
3. The suspension components may only be installed by trained technical personnel using the proper tools.
4. The General Installation instructions, as well as the Technical Inspectorate (German TÜV) documents must be read **BEFORE** attempting installation.
5. Never use impact wrenches or guns to install or remove shock absorber piston hardware.
6. Never disassemble or cut open shock absorbers and/or shock absorber inserts. They contain oil under pressure. Danger of explosion.
7. Before driving on public highways, carry out the work steps on page 7, items 11 through 14 after installation.
8. Please take care in any case that fittings (for example fittings of shock absorber housings or fittings of the lower control arm in the housing of the wheel bearing) are free of dust and oil. (see manufacturer guideline)

General Instructions for Use:

1. When adjusting the vehicle height, make sure that the threads are clean and free of debris. After initial cleaning, move the perch by 10 mm (0.4 Inches) downwards, and then clean the area that you desire to adjust the perch (up or down).
2. During height adjustments on separate shock and spring systems, remove the perch from the vehicle to adjust the height.
3. After adjusting the vehicle height, repeat steps 11 through 14 from page 7.
4. In the area of the piston rod and the sealing package of the new and used damper might be oil and grease collected. This could either be caused by using a special black grease during assembling the washer or due to accumulation of streak oil. Further more oil is used during assembling the cartridge and rod guide. There is no reason of worrying about and damage, as in this area also dust and dirt used to be collected.

Tightening torque for the piston rod nut:

M8 = **25Nm (18 ft-lb)**, M10x1 = **20Nm (15 ft-lb)**, M10x1,25 = **20Nm (15 ft-lb)**, M12x1,25 = **35Nm (26 ft-lb)**,
M12x1,5 = **40Nm (29 ft-lb)**, M14x1,5 = **50Nm (37 ft-lb)**, M16x1,5 = **50Nm (37 ft-lb)**

Installation Instructions			KW automotive	
Instruction No.	688 10 00K		Date	11.08.2021



General Mounting Specifications:

1. We recommend the use of a vehicle hoist or lift when installing the suspension.
2. **Caution:** If the vehicle is equipped with ride height sensors, they should be removed before removal of struts or dampers, otherwise damage may occur.
3. The struts should be removed as specified by manufacturer's instructions.
4. Manufacturer recommended tools for removal of the original struts, or a suitable spring compressor, must be used in order to remove most factory mounted suspension systems.
5. Mount the complete suspension system as described on the following pages.
6. Never use impact drivers to install nuts on the piston rods as permanent damage may occur. It is imperative that you do not damage the piston rod surface, through use of pliers etc, as the smallest damage will result in seal damage, and will not be covered under warranty.
7. Stay within the lowering range specified in the table on page 3.
Example: With a specified range of 20 - 60 mm (0.8 - 2.3 Inches), 40 mm (1.5 Inches) is your height adjustment range.
8. Ensure that the set screw on each spring collar is tightened to prevent movement of the spring perch. On vehicles with separate shock/spring combinations, no set screw is necessary.
Caution: Do not over tighten the set screw. Maximum torque is 1 - 2 Nm (0.74-1.47 ft-lb).
9. Install the suspension components in the vehicle as specified by the vehicle manufacturers in their document.
10. Except as noted, all torque values must comply with manufacturer recommended specifications.
11. After assembly and installation is complete, the vehicle should be rolled onto level ground. Once on level ground, measure the vehicle height and adjust to the customer's requirements, within the prescribed lowering range.
Caution: Wheel hub center—wheel arch maximum measurement in the table of page 3 must not be exceeded! Also take into account minimum road clearances specified in the table on page 7 (only valid for Germany!).
Caution: It is common for the vehicle suspensions to settle by an additional 5 - 10 mm (0.2 - 0.4 Inches)
12. Examine the clearance between the tires and the suspension over the full range of motion of the wheel. The minimum clearance between the suspension and the tire is 4 mm (0.16 Inches). If this clearance is less than 5 mm (0.2 Inches), wheel spacers may be necessary. With strut designs that are located close to the wheel, but that have no steering functions, use 100 mm (3.9 Inches) spacers on diagonally opposed wheel (e.g. front right, rear left). In this position, you must be able to achieve the minimum clearance required. You can also check the clearance between tire and body.
Caution: With torsion beam trailing arm axles, this method is not sufficient. The wheel must be under full load as well as test driven to properly calculate the clearances of 5 mm (0.2 Inches) from any other components.
13. The geometry of the suspension needs to be adjusted according the regulations of the vehicle manufacturer. If a value cannot be reached due to the difference in the height, a optimal value next to the tolerance range of the vehicle manufacturer needs to be adjusted.
14. All components that are controlled by vehicle ride height (e.g. headlights, brake bias regulator etc.) must be adjusted as specified by the vehicle manufacturer instructions and procedures.
15. For vehicles with ESP, DSC or EPC your new suspension components may cause an engine fault code to appear. This is only temporary as the vehicle electronics adjust to the new components/height. On some models this will end after driving approximately 3-5 miles, or through turning the steering wheel from full left to full right. On other models, this must be reset through the factory diagnostic port by a qualified technician.

Installation Instructions			KW automotive	
Instruction No.	688 10 00K		Date	11.08.2021

Front axle:

Important: Do not disconnect the hydraulic lines of the coilover strut.

For the disassembling of the original spring, the following parts must disassemble by manufacturers' instructions: 1. Damper fixing screw
2. Upper wishbone.



Installation Instructions

KW automotive


Instruction No.

688 10 00K

Date

11.08.2021

Dismantle the top mount connection.



Flap the complete strut out of the wheelhouse.

Dismantle the topmount with a correct tool.

Note: At this vehicle it was possible to dismantle the spring without a spring clamp. We recommend a spring clamp to use.

Installation Instructions

KW automotive

Instruction No.

688 10 00K

Date

11.08.2021

Remove the standard spring, standard bumpstop and the standard dust cover. In the next Stepp remover (pull) the molded ventilation disk **1** and the spring perch **2**.



Installation Instructions

KW automotive

Instruction No.

688 10 00K


Date

11.08.2021



Dismantled coilover strut.

Insert the supplied threaded bush 1 and the standard ventilation disk 2 on the coilover strut.



Installation Instructions

KW automotive

Instruction No.

688 10 00K

Date


11.08.2021

Insert the following supplied parts in the same succession: Helper spring 1, Intermediate ring 2, Bumpstopp with dustcover 3 and spring 4.



Mount the intermediate ring with the small collar towards to the helper spring.

5 mm /
0,2 inch



Installation Instructions

KW automotive

Instruction No.

688 10 00K

Date

11.08.2021

Install the original supporting bearing with the original spring rubber and fix it with the standard nut. Please install the strut unit to manufacturers recommended settings regarding tightening torque and fixing specifications.



Installation Instructions

KW automotive


Instruction No.

688 10 00K


Date

11.08.2021

Rear axle:



The height adjustment is used with a plastic and stainless steel disc at the top. The standard upper spring pad is no longer used. The provided aluminium spacer has to be mounted between the height adjustment and chassis. To correct the vehicle height, please remove the height adjustment



Use the original spring support at the bottom end of the spring.

Installation Instructions

KW automotive


Instruction No.

688 10 00K

Date

11.08.2021

Important: Do not disconnect the hydraulic lines of the damper.



Dismantle the damper.



Dismantle the topmount with a correct tool.

Installation Instructions

KW automotive

Instruction No.

688 10 00K

Date

11.08.2021



Remove the Standard bumpstop with dustcover.

Installation Instructions

KW automotive

Instruction No.

688 10 00K

Date

11.08.2021

Put on the following supplied parts: 1 bumpstop with dustcover and 2 addition bumpstop.



Install the original supporting bearing and fit with the standard nut. Please install the damper unit to manufacturers recommended settings regarding tightening torque and fixing specifications.

Learn more about performance suspension parts we have.