

STAINLESS WORKS

2010+ CAMARO V8 MUFFLER DELETE INSTALLATION INSTRUCTIONS (CA10DEL)

Thanks for purchasing a Stainless Works Muffler Delete System for your 2010+ Camaro V8. We have gone to great pains to make sure that our exhaust systems fit and sound great. Please follow these steps to ensure that your installation goes as planned.

Disassembly

1. Disconnect battery.
2. Raise and support vehicle.
3. On the inlet side of both mufflers, measure 2" and mark the tubes for cutting.
4. Using a hacksaw or similar type fine tooth cutter (or large exhaust tubing cutter), cut the muffler inlets at the marks. See picture below.



5. Remove the mufflers from the hangers and take down.
6. Deburr the remaining tailpipes. The Muffler Delete pipes will slip over these tailpipes.

Installation

1. Install (2) 2.5" dia. clamps over the notched ends of the 3" pipes and assemble them on the tailpipes. Snug a bit, but do not tighten yet.



2. Install tips and the 3" hanger clamps. See picture below.



3. Adjust as needed, and tighten from front to rear.
4. Lower vehicle and reconnect battery.
5. After double checking for clearance, drive the car for 10-20 miles and re-check all clamps and clearances.