



70°-100° F (Install temp.)

- 1** This product is designed to be placed inside the window channel. Lower the window. Clean window channel with alcohol pad.
- 2** Remove the tape liner from the front and rear flanges. Peel back 2" of tape liner from each end of top flange.
- 3** Insert visor into window channel, front flange first. Front flange inserts **between rubber trim and the mirror cap**. Top flange slides into window channel. Rear flange slides **between the post and window trim**.
- 4** Remove tape liner by pulling on free ends. Raise window slowly and leave up for 24 hours to secure.
- 5** Install rear visor. Top and rear flanges slide into the window channel and front flange fits **between the post and window trim**.



IMPORTANT: Clean with a **SOFT** cloth and soap and water **ONLY!** Using abrasive cleaners, chemicals, or solvents will **VOID** the warranty on this product.