

# 126941 ALT. B

## INSTALLATION INSTRUCTIONS FOR 800 AMP CLAMPS AND JAW KIT

Hold clamp open by wrap of friction tape around handles. Insert cable under clamp spring. Strip cable 1/2". Be sure wires are free of corrosion. Crimp cable onto copper jaw with a crimping tool or vise. Bolt parts into place in sequence illustrated.

