

GF10768B

Nylon E or F Connector Installation Instruction

1. If either E or F connector is required, immerse in hot water for 20 to 30 seconds to soften the nylon for ease of installation on valve.
2. If the valve assembly removed from the engine has a nylon L connector, use the attached plug or the enclosed rubber cap to plug the upper outlet of the F connector.

