

STANDARD®

610020B

Voltage Regulator Installation Instructions

Important Notice: Test the battery to verify that it is fully charged before installing the new regulator. An undercharged battery can cause a good regulator to appear defective.

Disconnect negative battery cable.

Remove wires from terminals noting the location of each wire.

Remove old regulator by removing mounting screws.

Install new regulator and reinstall mounting screws.

Re-attach wires to the same terminals as original unit.

Reconnect negative battery cable.

Polarize Regulator — Caution: Follow these instructions exactly.

Disconnect the wire at the regulator terminal marked FLD.

Momentarily (no longer than 2 seconds) touch the wire to the BAT terminal. There may be a brief spark; this is normal.

Reconnect the wire to the field (FLD) terminal.

Start vehicle and check charging system for proper operation.

