

## **INSTALLATION INSTRUCTIONS** 3" OVAL BENT END SIDEBARS 2019 CHEVY SILVERADO 1500 REGULAR CAB

## 3" OVAL BENT END SIDEBARS 2019 CHEVY SILVERADO 1500 REGULAR CAB

	ng Bracket	1 4 4 4 Driver/ Mount	1/2" x 2" Hex Bolt 1/2" Lock Washer 1/2" x 1-1/2" x 1/8	S
Front Mounting Bra Right Front Mounti Rear Mounting Bra nt Pa	ng Bracket cket assenger/Right	4 4 Driver/ Mount	1/2" x 2" Hex Bolt 1/2" Lock Washer 1/2" x 1-1/2" x 1/8	s s " Flat Washers Driver/Left
Front Mounting Bra Right Front Mounti Rear Mounting Bra nt Pa	ng Bracket cket assenger/Right	4 Driver/ Mount	1/2" x 1-1/2" x 1/8 /Left ting Bracket	" Flat Washers Driver/Left
Right Front Mounti Rear Mounting Bra nt Pa	ng Bracket cket assenger/Right	Driver/ Mount	/Left ting Bracket	Driver/Left
Rear Mounting Brant	cket assenger/Right	Mount	/Left ting Bracket	Driver/Left
Pa		Mount	ing Bracket	
Passe	enger/Right Sideba	ır		Front
	Passe	Passenger/Right Sideba	Passenger/Right Sidebar	Passenger/Right Sidebar

## PROCEDURE:

REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. ASSISTANCE IS RECOMMENDED.

- 1. Start the installation under the Passenger/Right side of the vehicle. Locate the front body mount, (Figure 1). Remove the front body bolt.
- 2. Select the Passenger/Right Front Mounting Bracket. Reuse the factory body bolt to attach the Bracket to the body mount, (Figures 2 & 3). Do not tighten hardware at this time.
- 3. Move to the rear mounting location, (Figure 4). Repeat Steps 1 & 2 to attach the Passenger/Right Rear Mounting Bracket to the rear body mount, (Figures 5 & 6).
- 4. Carefully unwrap and select the Passenger/Right Sidebar. Use the illustration above to help identify the correct Sidebar. Attach front of the Sidebar to the bracket with (1) 1/2" Hex Bolt, (1) 1/2" Lock Washer and (1) 1/2" Flat Washer, (Figures 7 & 8). Do not tighten hardware.
- 5. Repeat Step 4 to attach the rear of the Sidebar to the Rear Bracket, (Figures 9 & 10). Do not tighten hardware at this time.
- 6. Level and adjust the Sidebar as necessary and fully tighten all hardware.
- 7. Repeat Steps 1-6 for Driver/Left Sidebar installation.
- 8. Do periodic inspections to the installation to make sure that all hardware is secure and tight.

## 3" OVAL BENT END SIDEBARS 2019 CHEVY SILVERADO 1500 REGULAR CAB

**To protect your investment**, wax this product after installing. Regular waxing is recommended to add a protective layer over the finish. Do not use any type of polish or wax that may contain abrasives that could damage the finish. Mild soap may be used also to clean the Sidebar.





