



**INSTALLATION INSTRUCTIONS
STILLEN FRONT LICENSE PLATE BRACKET**

Materials supplied:

1. Shaft
2. Bracket
3. Stainless cap screws
4. Serrated flange nut
5. M10 Flat SHCS
6. (3) Serrated lock washer

Equipment needed:

1. Assorted allen wrenches
2. Assorted wrenches
3. Loctite©

Installation:

1. Remove plug in front fascia that covers the tow hook mounting hole. Be careful not to scratch the paint.
2. Tighten the aluminum shaft into the tow hook hole.
3. Apply some Loctite to the countersunk bolt and mount the black bracket to the aluminum shaft using the countersunk lock washers, with two behind and one in front of the bracket. Be sure the bracket is level. Tighten this bolt firmly.
4. Install the license plate and frame using the stainless cap screws and flange nuts.
5. Done