



INSTALLATION INSTRUCTIONS

Stiller Front Spoiler
NISSAN 300ZX (NA motor)
PART NUMBER 108811

Materials supplied:

1. 4 1/8" Rivets
2. Front spoiler

Equipment needed:

1. Pop-rivet gun
2. Electric drill with 5/32" (or No,20) drill bit.

Installation:

1. The first step is to pre-fit the spoiler prior to painting. This ensures proper fit and alignment prior to painting. Once the spoiler has been painted it is sure to fit without further inconvenience.
2. After painting is done slide spoiler over the top of the existing front valence.
3. Drill and install rivets where the spoiler folds around into the wheel well.
4. You may want to install more rivets in each side of the radiator air inlet opening.
5. **DONE!**