



INSTALLATION INSTRUCTIONS
Stillem Signature Oil Filler Cap
P/N 400350

Materials supplied:

1. Stillem Oil Cap w/ O-ring
2. Stillem Badge

Installation:

1. Remove Stillem badge from oil filler cap. It is held on with tape.
2. Remove OEM oil filler cap.
3. Install Stillem Signature Oil Filler Cap.
4. Remove the backing from the badge and align the badge so it is read from the front of the car and apply to oil filler cap.
5. Done!



Stillem Badge

Stillem Signature Oil Filler Cap



Your Stillem Signature Oil Filler Cap should look like this when completed.