



INSTALLATION INSTRUCTIONS
"Z" TUBE
INFINITI G35 / G35X / FX35

Parts supplied.

1. Inlet tube

Tools required.

1. Screwdrivers
2. Pliers
3. Silicone spray lube. (optional)



WARNING:

IF YOU ARE NOT EXPERIENCED IN THIS AREA OF AUTOMOTIVE MECHANICS WE STRONGLY URGE THAT YOU REFER THIS INSTALLATION TO YOUR MECHANIC.

Installation:

1. Remove the stock intake tube.
2. The new intake will install with the PCV port on the bottom, pointing to the rear of the vehicle. Transfer the rubber flex boot and the rubber elbow to the new intake tube. Do not tighten the clamps yet.
3. Install the new tube and connect the PCV hose to the bottom. A little spray lube will make the tube install easier.
4. Twist the inlet tube until the tube, rubber elbow and throttle body are aligned.
5. Tighten all clamps.
6. Done.