



INSTALLATION INSTRUCTIONS

STILLEN PERFORMANCE EXHAUST
2008 NISSAN ALTIMA COUPE
P/N 508275

Materials supplied:

1. (1) Stillen Performance Exhaust Assembly
2. (1) Clamp

Equipment needed:

1. Assorted sockets and wrenches
2. Floor jack
3. (2) Jack stands

Installation:

1. Removal of OEM muffler
 - a. Jack the rear of the vehicle up and support on jack stands under the frame in the manufacturers specified locations. Make sure to block the front wheels to prevent the vehicle from rolling. Alternatively, it would be best to *have the vehicle raised on a hydraulic lift.*
 - b. Disconnect the grounding strap located on the right side muffler.
 - c. Loosen and remove the nuts on the exhaust flange.
 - d. Remove the hangers from the two rubber bushings on the left side muffler and from the mounting bracket on the right side muffler.
 - e. Remove the muffler assembly from the vehicle.
2. Installation of the Stillen Performance Exhaust
 - a. On the right side muffler, hook the hanger on the mounting bracket (Fig. 1).
 - b. Mount the exhaust flange and secure with the stock bolts, nuts and gasket.
 - c. Insert the slip joint on the left side of the exhaust and attach the two exhaust pipes together (Fig. 2).
 - d. On the left side muffler, hook the hangers on the stock bushings (Fig. 3).
 - e. Attach the grounding strap to the right side muffler using the stock nut previously removed.
 - f. Start the vehicle and check your installation for leaks.
3. **DONE!**



WARNING:

IF YOU ARE NOT EXPERIENCED IN THE AREA OF
AUTOMOTIVE MECHANICS WE STRONGLY URGE THAT
YOU REFER THIS INSTALLATION TO YOUR MECHANIC.

