



STREET SCENE EQUIPMENT, INC.

950-74143 SATIN FINISH
&
950-74143 CHROME FINISH
CHEVY SILVERADO / GMC
& SIERRA
SSE VALANCE GRILLE
3 PC. SET

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

NOTE:

FITS STREET SCENE BUMPER COVER'S PART NUMBER'S 70143, 70144, 70165

PARTS LIST					
3 PC	Speed Grille Set	1	Instruction Sheet	10	Installation Clips # 71099
1	Street Scene Decal	1	Street Scene Emblem	8	Installation Clips # 71098
				1	Care For Grilles

TOOL LIST
NO TOOLS REQUIRED

NOTE:

We highly recommend installing Speed Grilles into valance before installing valance on vehicle.

1. Install Speed Grille inserts into their respective openings. From the backside, clip the side grilles using **FOUR** of the 71098 clips 3/4" long. Refer to illustration. Install the center Speed Grille into opening "clip" in the same manner using **FIVE** 71099 1" long clips on the top side and **FIVE** 71099 1" long clips on the bottom side.

Typical Clip Installation

