



# STREET SCENE EQUIPMENT, INC.

950-76176 BLACK CHROME  
950-77176 SATIN FINISH  
950-78176 CHROME FINISH  
950-79176 STAINLESS STEEL  
2007  
CHEVY SILVERADO  
SPEED GRILLE INSERTS

## INSTALLATION INSTRUCTIONS

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Upper Speed Grille Insert	1	Instruction Sheet	16	Ladder Ties
1	Lower Speed Grille Insert	1	Street Scene Emblem	1	Care For Grilles

TOOL LIST	
6 MM Socket, Ratchet, Side Cut Pliers	

1. Open hood.
2. Remove the top cover panel by removing the push in fasteners.
3. Remove the four 6 MM head screws securing the grille shell to vehicle.
4. Lift up slightly and pull the grille shell forward to unsnap the six metal push in fasteners.
5. The Speed Grille inserts will install over the existing X member grids in grille shell.
6. Insert the ladder ties through the loop in Speed Grille and around the plastic X's in grille shell. Use eight ladder ties per Speed Grille section. Two at each end ( Top & Bottom ) and equally place the other two across the Speed Grille. Install **ALL** ties first before pulling tight. Cut off excess ties.
7. Install Grille Shell back onto vehicle making sure it snaps in securely. Before installing the four screws removed in step three. Lift the grille shell up slightly to make sure the two vertical tabs by the center screws are positioned correctly. Tighten snugly and install to the panel.
8. Re-install top cover panel.