



# STREET SCENE EQUIPMENT, INC.

950-76931 BLACK CHROME  
&  
950-77931 SATIN FINISH  
&  
950-78931 CHROME FINISH  
2005  
FORD MUSTANG 6 CYL.  
**MAIN GRILLE INSERT**

## INSTALLATION INSTRUCTIONS

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

**NOTE: Fits 6 CYL. Models Only  
For GT Models Use 950-7X932**

PARTS LIST					
1	Speed Grille Insert	1	Instruction Sheet	8	Push In Fasteners
4	11" Cable Ties	1	Street Scene Emblem	1	Care For Grilles Sheet

TOOL LIST	
Flat Blade Screwdriver, Side Cut Pliers, Drill Motor, 1/4" Drill Bit	

1. Open hood.
2. Remove the air deflector panel between the front fascia and radiator by prying up the " push in " fasteners securing the panel.
3. Remove the grille by lifting the center tabs on fascia with a small screwdriver while pulling grille forward.
4. Remove the Mustang Emblem.
5. Refer to photo and drill 1/4" holes in grille as indicated.

### PHOTO



Passenger Side Of Grille Shell



Driver's Side Of Grille Shell

6. Install cable ties through Speed Grille in an obscure place and attach to grille shell by pushing both ends through the holes drilled in step five and fastening in backside. Tighten cable ties snugly. DO NOT overtighten. Cut off excess.
7. Install grille back into fascia making sure all attaching points are tight.
8. Install air deflector panel removed in step two using the new " push in " fasteners supplied.