



# STREET SCENE EQUIPMENT, INC.

**950-77108 SATIN FINISH**  
**&**  
**950-78108 CHROME FINISH**  
**SPEED GRILLE**  
**1988 - 1998**  
**CHEV / GMC**  
**WITH STREET SCENE**  
**950-70108 BUMPER COVER**

## INSTALLATION INSTRUCTIONS

**VERY IMPORTANT !** Read and understand all directions, then check the following parts list before starting installation.

PARTS LIST					
1	Speed Grille Insert	1	Instruction Sheet	4	Attaching Clips # 71098
1	Got Street Scene Decal	1	Street Scene Decal	3	Speed Nuts
				3	Black Washer Head Screws

TOOL LIST
Phillips Head Screwdriver, Drill Motor, 3/16 Drill Bit

1. Install the Speed Grille into the opening with the short side facing up. Clip Grille at each end and center the two remaining clips between. From the bottom side of the valance drill through into Speed Grille holes in center and at each end. Attach with speed nuts and screws provided.

