



STREET SCENE EQUIPMENT, INC.

950-77118 SATIN FINISH
950-78118 CHROME FINISH
2006 - 2007
CHEVY TRAILBLAZER SS
MAIN GRILLE INSERTS

INSTALLATION INSTRUCTIONS

SPEED GRILLE INSERTS FIT SS MODEL ONLY

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Upper Grille Insert	1	Instruction Sheet	6	1/4" Push In Fasteners # 18379
1	Lower Grille Insert	1	Street Scene Emblem	12	Ladder Ties # 10060
1	Care For Grilles				

TOOL LIST	
Drill Motor, 1/4" Drill Bit, Side Cut Pliers	

1. Remove the grille shell from vehicle.
2. Insert the lower Speed Grille onto the grille shell by first inserting the top under the bow tie area and then pushing the bottom in.
3. From the back side secure the Speed Grille to the grille shell using eight of the black tie straps included. Using four on the bottom and four on the top, install the tie straps through the loop on Speed grille and then around the " X " member in the grille shell. Install all tie straps first before pulling tight. Cut off excess.
4. Insert the upper Speed Grille section onto the grilleshell. The top of the Speed Grille will rest on the top of the grille shell. Looking at the top of the Speed Grille you notice six " Loop's " that extend out past the grille edge. Drill a 1/4" hole thru these loops and into the top of the grille shell.
5. Fasten the top of the Speed Grille to the grille shell using the six push in fasteners supplied. Secure the bottom of the Speed Grille using the four remaining tie straps in the same manner as the bottom.
6. Install grille shell back into vehicle.