



STREET SCENE EQUIPMENT, INC.

950-77119
BUMPER COVER / VALANCE
SPEED GRILLE
1998 - 2000 GMC
"S" SERIES

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation. Installation time is approximately 1/2 hour.

PARTS LIST					
1	Speed Grille Section	1	Instruction Sheet	8	Attaching Clips (#71098)
		1	Street Scene Decal	1	Got Street Scene Decal

TOOL LIST
None required

1. Before beginning installation be sure to wear proper eye protection.
2. If you are installing the SSE 950-70119 valance, install the "Speed Grille" into the valance before installing the valance onto the truck. If valance is already installed, It is not necessary to remove it to install the "Speed Grille" insert.
3. Remove the "Speed Grille" from it's protective package.
4. Slide the "Speed Grille" into the opening making sure the grille is centered. **Note:** the top is the wider of the two sides.
5. Attach the "Speed Grille" to the valance by sliding the clips over the valance and "Speed Grille" from the back side.
6. Locate the clips at the outer most ends and equally across the grille. Use 4 clips along the top and 4 along the bottom sides.
7. Make sure the grille is securely attached.