



STREET SCENE EQUIPMENT, INC.

950-77122
1999 - 2001
CHEVY SILVERADO
&
2000 - 2001
TAHOE / SUBURBAN
SSE [VALANCE GRILLE](#)

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation. Installation time is approximately 10 minutes.

NOTE: INSERT ONLY FITS STREET SCENE VALANCE PART # 950-70122

PARTS LIST					
1	Speed Grille Section	1	Instruction Sheet	5	Installation Clips # 71098
1	Got Street Scene Decal	1	Street Scene Emblem	5	Installation Clips # 71095

TOOL LIST	
No Tools Required	

1. Raise front end of vehicle.
2. Install Speed Grille insert into opening. Clip from back side using the clips provided. Use clip length as necessary.
3. Install the Street Scene Emblem on the grille face. Remove the protective cover.