



# STREET SCENE EQUIPMENT, INC.

950-77124 SATIN FINISH  
 950-78124 CHROME FINISH  
 2006  
 CHEVY TRAILBLAZER  
 SS LOWER VALANCE  
**SPEED GRILLE INSERTS**

## INSTALLATION INSTRUCTIONS

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
<b>3 PC SET</b>	Speed Grille Inserts	<b>1</b>	Instruction Sheet	<b>16</b>	Installation Clips # 71098
		<b>1</b>	Street Scene Emblem	<b>1</b>	Care For Grilles

TOOL LIST	
Flat Blade Screwdriver	

1. Remove the three black ABS grilles from the bumper cover. Pry up the tabs with a flat blade screwdriver to remove.
2. Insert the side Speed Grilles into the chrome air vent openings. Clip from the back side using two of the clips on the top and two on the bottom.
3. Insert the center Speed Grille into the opening fasten by clipping in the same manner. Use four clips across the top and four across the bottom.

### TYPICAL CLIPPING INSTALLATION

